


Nº	CODE	DESCRIPTION	Nº	CODE	DESCRIPTION
1	BPC81401	MOTOR HOUSING	27	BP11721	SPRING PIN
2	BPC81402	SPRING PIN (2X24)	28	BPC81421	HAMMER CASE
3	BPC81403	AIR INLET	29	BPC81422	O-RING (37.8X1.6)
4	BPC81404	TRIGGER	30	BPC81423	GASKET
5	BPC81405	O-RING	31	BPC81424	GASKET
6	BPC81406	REVERSE VALVE	32	BPC81425	WASHER
7	BPC81407	EXHAUST DIFFUSER	33	BPC81323	HAMMER CAGE
9	BPC81408	FORWARD BUTTON	34	BPC81324	HAMMER (2)
10	BPC81409	REVERSE BUTTON	35	BPC81325	HAMMER PIN (2)
11	BPC81410	O-RING	36	BPC81426	ANVIL 1/2"
12	BPC81411	RETAINING RING	37	BPC81327	O-RING
13	BPC81309	BALL BEARING	38	BPC81328	RETAINING RING
15	BPC81412	ROTOR	39	BPC81427	O-RING
16	BPC81312	ROTOR BLADE (6)	41	BPC81428	O-RING 15.54X2.62 (3)
17	BPC81413	SPRING PIN	42	BPC81429	VALVE SPRING
18	BPC81414	CYLINDER	43	BPC81330	VALVE STEM
19	BPC81415	FRONT END PLATE	44	BPC81430	RUBBER SPACER
20	BPC81316	BALL BEARING	45	BP11002	SPRING PIN
21	BPC81416	AIR REGULATOR	46	BPC81431	SCREW M4X80 (4)
22	BPC81417	O-RING (32X1.5)	47	BPC81332	MUFFLER MATERIAL
23	BPC81418	SPRING	48	BPC81432	MUFFLER MATERIAL
24	BPC81419	STEEL BALL 9/64"	58	BPC81433	PARTITION
25	BPC81420	ANVIL BUSHING	59	BPC81434	SCREW (TS2.2X10)
26	P82371	OIL CAP			



BPC814



SNA Europe does not cover the causes over negligence in tool use and/or repair, inadequate care, or abnormal usage conditions. Follow the instructions for proper use, safety, maintenance and servicing given by SNA Europe